



ergonomic products

K&A MANUFACTURING

6703 ZINSER ST., SCHOFIELD, WI 54476

PHONE: 800.298.4351 FAX: 866.882.9475

www.raproducts.com

VERSION DATED: 9/8/11

TOOLS REQUIRED FOR ASSEMBLY:
FLAT BLADE SCREWDRIVER WITH
A THIN BLADE

**READ ALL THE INSTRUCTIONS
BEFORE BEGINNING**

**NewGas WORKSTATION INSTRUCTIONS FOR REPLACEMENT OF THE
CABLE PADDLE:**

STEP 1: INSERT THE BLADE OF THE SCREWDRIVER BETWEEN THE BLADES OF THE CABLE PADDLE ASSEMBLY. SEE THE DRAWING BELOW AND PICTURE 1.

STEP 2: WITH A SLIGHT TWIST OF THE SCREWDRIVER BLADE, PULL THE CABLE PADDLE OUT OF THE BASE AND TURN IT 180° AS SHOWN ON PICTURE 2.

STEP 3: REMOVE THE END OF THE CABLE AND THE STOP FROM THE SLOT ON THE PADDLE. THE CABLE PADDLE IS NOW FREE OF THE BASE AS SHOWN IN PICTURE 3.

STEP 4: INSERT THE CABLE AND THE STOP INTO THE SLOT ON THE NEW CABLE PADDLE.

STEP 5: INSERT ONE END OF THE NEW CABLE PADDLE INTO THE HOLE ON THE BASE AS SHOWN IN PICTURE 4 AND THE DRAWING BELOW. PRY THE SIDES OF THE BASE APART AND POP THE OTHER END OF THE CABLE PADDLE INTO THE OTHER HOLE ON THE BASE.



PICTURE 1



PICTURE 2



PICTURE 3



PICTURE 4

