

Threaded Insert Instruction

Warranty: raproducts.com/warranty

Step 1

- Disregard wood screws in hardware pack and use supplied machine screws.

