



ergonomic products

K&A MANUFACTURING

6703 ZINSER ST., SCHOFIELD, WI 54476

PHONE: 800.298.4351 FAX: 866.882.9475

www.raproducts.com

VERSION DATED: 9/8/11

TOOLS REQUIRED FOR PROCEDURE:

- CORDLESS DRILL
- #2 PHILLIPS HEAD DRIVER BIT

NewGas WORKSTATION INSTRUCTIONS TO RELOCATE CABLE RELEASE CLAMP TO CORRECT THE PROBLEM OF THE WORKSURFACE CREEPING UP:

STEP 1: INSPECT THE UNDERSIDE OF THE WORKSURFACE TO SEE IF THE RELEASE CABLE COMES OUT OF THE WORKSURFACE STRAIGHT.

STEP 2: IF IT COMES OUT AT AN ANGLE (SEE PICTURE BELOW LEFT), FULLY EXTEND THE WORKSTATION. LAY THE WORKSTATION UPSIDE DOWN ON A PROTECTED SURFACE. THIS WILL BE EASIER TO DO WITH A HELPER.

STEP 3: REMOVE THE SCREW FROM THE CLAMP. RELOCATE THE CABLE CLAMP TO A SPOT WHERE THE CABLE WILL EXIT THE WORKSURFACE SUPPORT STRAIGHT. SEE THE PICTURE BELOW RIGHT.

STEP 4: REINSTALL THE SCREW AT THE NEW LOCATION. THIS IS A SELF DRILLING SCREW BUT IT MAY BE EASIER TO DRILL A 7/64" PILOT HOLE. FULLY TIGHTEN THE SCREW.

IF THIS PROCEDURE DOES NOT CORRECT THE PROBLEM OF THE WORKSURFACE CREEPING UP, CONTACT RA PRODUCTS AT THE NUMBER SHOWN ABOVE LEFT.



RELEASE CABLE SHOWN EXITING THE WORKSURFACE SUPPORT AT AN ANGLE



RELEASE CABLE SHOWN EXITING THE WORKSURFACE SUPPORT STRAIGHT